


M - VACUUM DIAGRAMS
1989 ENGINE PERFORMANCE Honda Vacuum Diagrams

AUTOTRONICA Y ELECTRONICA PORTUGAL

Fig. 1: Vacuum Diagram for 2.0L Carb. with A/T (1 of 3)
Courtesy of AMERICAN HONDA MOTOR CO., INC.
 1989 Honda Accord DX



- 14. Primary Slow Mixture Cut-Off Solenoid Valve
- 15. Air Control Valve "B"
- 16. Catalytic Converter
- 17. Fast Idle Unloader
- 18. Throttle Controller
- 19. Frequency Solenoid Valve "B"
- 20. Constant Vacuum (CV) Generator
- 21. Frequency Solenoid Valve "A"
- 22. Check Valve "A"
- 23. Vacuum Chamber
- 24. Frequency Solenoid Valve "C"
- 25. Air Control Valve "A"
- 26. Check Valve "B"
- 27. EGR Valve
- 28. EGR Control Valves "A" & "B"

- 1. Intake Air Temp. Control Check Valve
- 2. Intake Air Control Diaphragm
- 3. Cranking Leak Solenoid Valve
- 4. Thermovalve "C"
- 5. Check Valve "E"
- 6. Thermovalve "B"
- 7. Air Jet Controller
- 8. Air Bleed Valve "A"
- 9. Air Bleed Valve "B"
- 10. Thermovalve "A"
- 11. Feedback Control Solenoid Valve
- 12. Oxygen Sensor
- 13. Choke Opener

- 29. Anti-Afterburn Valve
- 30. Anti-Afterburn Control Solenoid Valve
- 31. Vacuum Holding Solenoid Valve
- 32. Air Suction Valve
- 33. Air Suction Control Solenoid Valve
- 34. Vacuum Switch "A"
- 35. Air Leak Solenoid Valve
- 36. Vacuum Switch "B"
- 37. Idle Boost Solenoid Valve
- 38. A/C Idle Boost Solenoid Valve
- 39. Purge Control Valve
- 40. Charcoal Canister
- 41. Two-Way Valve